

CONDOR ® UBS-2000 ULTIMATE BIKE STAND USER INSTRUCTION MANUAL

STOP! WARNING: READ THIS FIRST!

First read and understand the instruction manual and product labels for important safety, set-up and troubleshooting information. If you have problems setting up or using the UBS-2000 Ultimate Bike Stand by Condor ® , contact customer service at (815) 754-7418 or contact us via email @ www.condor-lift.com. The UBS-2000 Ultimate Bike Stand by Condor ® is not intended for use by children.



Instructions:

1. Remove the UBS-2000 from packaging and place the unit on the ground in front of motorcycle with the pivot lifting arm on the left front side of the unit as shown in Figure 1.
2. Roll the bike forward over the unit until the rear tire is positioned on the back of the base plate as shown in Figure 2.
3. Hold the bike securely upright with your left hand on the handlebar and your right hand on the rear of the bike from a secure location. Raise the side lever from the lower position to the upper position using your right foot as shown in Figure 3 and Figure 4. Continue holding the bike steady while pushing back and down on the foot lever to raise the platform up to the underside of the motorcycle's frame as shown in Figure 5.

Note: It might take several attempts to become familiar with the optimal location of the motorcycle with respect to the unit prior to lifting the bike off the ground.

4. Once the platform is firmly pressed against the underside of the bike, double check (while making sure that the bike is held securely upright) that the bike is centered and properly positioned in middle of the raising platform. While continuing to hold the bike securely upright, push the foot lever back and down while pulling back and guiding the bike into the upright position as shown in Figure 6.
5. Once the bike has been raised with the lever positioned back and down to the ground, locate the quick release pin attached to the unit as shown in Figure 7. Secure the unit in its upright position by inserting the pin into the hole as shown in Figure 8.
6. To lower the motorcycle off of the stand, first remove the pin shown in Figure 8. Take hold of both handle bars and simply push the motorcycle forward. The stand will collapse and the bike will be able to roll forward over the unit.

CAUTION:

Always make sure that all fasteners are tight and ball bearings are in place prior to use. Understand the limitations of this product and do not exceed these limitations. Always make sure that the unit's are at there optimum settings for the size of the motorcycle before use. Be sure to read and understand user instructions for the UBS-2000 Ultimate Bike Stand. If instructions are not clear, additional information is available at www.condor-lift.com or call (800) 461-1344. Technical Components Development & Design is not responsible for any damage incurred by exceeding this product's limitations in structure and/or functionality.

One Year Limited Warranty:

This UBS-2000 Ultimate Bike Stand product warranty extends to the original consumer purchaser of the product. All illustrations and specifications contained in this manual are based on the latest product information available at the time of printing. Technical Components Development & Design, Inc. reserves the right to make changes at any time, without notice, in color, material, equipment, options, specifications and models. Models may be shown with optimal equipment. Further information may be obtained by contacting Technical Components Development & Design, Inc. at (815) 754-7418.

Return Policy:

15 Day return policy applies. Merchandise may be returned within 15 days of purchase. Merchandise must be unused and in its original packaging. Costumer must call Technical Components Development & Design, Inc. for a Return Authorization number. Return freight is at the responsibility and expense of the customers. Credit is given upon inspection of returned goods. A 15 % re-stocking fee applies to all returned merchandise.

Warranty Duration:

This product is warranted to the original consumer purchase for a period of one (1) year from the original purchase date.

What is not covered:

Our warranty will not cover abnormal wear of parts, damage resulting from negligent use of misuse of the product, use contrary to operating instructions, or disassembly, repair or alteration by any person other than an authorized service station. We shall not be liable for any incidental of consequential damages for breach of by express or implied warranty on products.

How your state's law may apply:

Some states do not allow limitations on how long any implied warranty lasts or the exclusion or limitation or incidental or consequential damages. So the above limitations may not apply to you. This warranty gives you specific rights, and you may also have other rights, which may vary from state to state.

Thank you for purchasing the Condor® UBS-2000 Ultimate Bike Stand.

Condor® is a trademark of Technical Components Development & Design, Inc.

The Condor® UBS-2000 Ultimate Bike Stand US Patented Number 6,575,310 & 6,648,300 & 6,935,619

210 Stephenie Dr.

Cortland, IL 60112

Phone: (815) 754-7418

Fax: (815) 754-7419

Website: www.Condor-lift.com



Figure 1



Figure 2



Figure 3



Figure 4



Figure 5



Figure 6



Figure 7



Figure 8